

# Canon PowerShot G2

## Camera Menu Configuration:

Option	Set to:
Resolution	L
Compression	S
File Format	JPEG
ISO Speed	50 or 100
Digital Zoom	OFF
AF Mode	Single
Light Metering	Spot
Spot AE Point	Center
Cont. Shooting	Default
Contrast	0
Sharpness	0
Saturation	0


Settings omitted here can be left at factory default, or set to user's preference.



# Canon PowerShot G2

## Normal Shooting Method:

### Before Starting:



Place camera in **Manual Mode** by rotating the MODE dial to the M position. Make certain that the camera's Menu Configuration matches that shown on the other side of the card.

Make certain that the camera is zoomed all the way back by pressing the MINUS magnifying glass zoom button.



Press the flash button until the flash is **DISABLED**.



Press the WB button and set the White Balance to **AUTO** or other setting that suits your environment.



Press the Selection Pad upwards until the Aperture setting reaches **F8.0**.

Press the Selection Pad to the left and right to adjust shutter speed. Use the rear screen view to tell when exposure appears optimal.

Take picture. Rotate camera and take second picture.

